

Care Guide



Safety Information - Read Before Installation

Choose a suitable location that meets all the requirements of the safety information.

- Carefully unpack all parts and check for damage or missing parts before commencing installation.

-Do not stand on this product, the product is intended to only be sat on.

-Take care, the chair may move while sitting into or standing up from the chair.

-Chair is not to be placed near an open fire or ignition source.

-80kg/ 176lbs maximum load. Do not exceed maximum load of the chair.

-Use on a firm and flat surface only.

-Children should be supervised around this product.

-Inspect the product for any damage before use.

-Furniture is for indoor use only.

Care Instructions - Read Before Installation

- This box contains fragile and valuable goods that have been carefully packed. Please take utmost care in unpacking the parcel as damage can occur in this process.

- Please be sure you have received the correct number of boxes i.e. 1 of 2, 2 of 2 etc.

- If you have received any damaged goods or are missing any part of your order, please contact our sales office as soon as possible.

Recycling

- Recyclable packaging used, please consult with your local recycling centre for further information.

-Waste electrical products should not be disposed of with conventional household waste. Please recycle all parts when possible.

Cleaning Instructions

Wood - only use a soft cloth.

Brass - all types: Use a soft dry lint free cloth.

Bronze, Nickel, Silver & Chrome: Use a dry cloth only, no chemical cleaners.

Glass: We recommend using a strong alcohol such as isopropyl alcohol. Note: some modern cleaning solutions can contain chemicals that can leave a greasy film on glass.

Gilt Wood: Use a dry cloth only.

Lacquered Furniture: Furniture polish

-Any decorative parts made from other materials must be removed and cleaned separately to avoid damage.

Cushion Care Guide

Spot clean marks or blemishes with a damp cloth and leave to dry.

Hand wash only: Remove the cushion cover from the foam.

Handwash the cover in clean cold water.

Leave to dry. Do not machine wash or tumble dry.

Care Guide



Safety Information - Read Before Installation

Choose a suitable location that meets all the requirements of the safety information.

- Carefully unpack all parts and check for damage or missing parts before commencing installation.
- Do not stand on this product, the product is intended to only be sat on.
- Take care, the chair may move while sitting into or standing up from the chair.
- Chair is not to be placed near an open fire or ignition source.

-80kg/ 176lbs maximum load. Do not exceed maximum load of the chair.

-Use on a firm and flat surface only.

-Children should be supervised around this product.

-Inspect the product for any damage before use.

-Furniture is for indoor use only.

Care Instructions - Read Before Installation

- This box contains fragile and valuable goods that have been carefully packed. Please take utmost care in unpacking the parcel as damage can occur in this process.

- Please be sure you have received the correct number of boxes i.e. 1 of 2, 2 of 2 etc.

- If you have received any damaged goods or are missing any part of your order, please contact our sales office as soon as possible.

Recycling

- Recyclable packaging used, please consult with your local recycling centre for further information.
- Waste electrical products should not be disposed of with conventional household waste. Please recycle all parts when possible.

Cleaning Instructions

Wood - only use a soft cloth.

Brass - all types: Use a soft dry lint free cloth.

Bronze, Nickel, Silver & Chrome: Use a dry cloth only, no chemical cleaners.

Glass: We recommend using a strong alcohol such as isopropyl alcohol. Note: some modern cleaning solutions can contain chemicals that can leave a greasy film on glass.

Gilt Wood: Use a dry cloth only.

Lacquered Furniture: Furniture polish

-Any decorative parts made from other materials must be removed and cleaned separately to avoid damage.

Cushion Care Guide

Spot clean marks or blemishes with a damp cloth and leave to dry.

Hand wash only: Remove the cushion cover from the foam.

Handwash the cover in clean cold water.

Leave to dry. Do not machine wash or tumble dry.