

Care Guide



Safety Information - Read Before Installation

Choose a suitable location that meets all the requirements of the safety information.

-Carefully unpack all parts and check for damage or missing parts before commencing installation.

-For use on a firm and flat surface only.

-Inspect the product for any damage before use.

-Table for indoor use only.

Keep these care guide instructions for future reference.

-Item is fragile - Handle with care.

-The glass used in this product is Safety glass.

-This product is not intended to be sat or stood on.

-Caution should be taken to not over load the table or one side more than the other. Overloading or misloading may result in injury or damage to the product.

-Children should be supervised around this product.

WARNING:

-Do not strike this surface with hard or pointed items or use the surface as a chopping surface.

-Do not place very hot or cold items directly on the glass surface.

-If the glass becomes scratched, chipped or broken, stop using the product immediately. This may cause unexpected breakage.

-Avoid impacts from the side, this is where glass is most vulnerable to breakages.

-Avoid using abrasive cleaning agents as these may scratch the glass and follow the cleaning instructions overleaf.

-In exceptional circumstances a scratched surface or damaged edge may cause the glass to break unexpectedly. The glass in this product is designed to break into small fragments rather than large / sharp pieces.

Care Guide

Care Instructions - Read Before Installation

- This box contains fragile and valuable goods that have been carefully packed. Please take utmost care in unpacking the parcel as damage can occur in this process.
- Please be sure you have received the correct number of boxes i.e. 1 of 2, 2 of 2 etc.
- If you have received any damaged goods or are missing any part of your order, please contact our sales office as soon as possible.

Recycling

- Recyclable packaging used, please consult with your local recycling centre for further information.
- Waste electrical products should not be disposed of with conventional household waste. Please recycle all parts when possible.

Cleaning Instructions

Wood - only use a soft cloth.

Brass - all types: Use a soft dry lint free cloth.

Bronze, Nickel, Silver & Chrome: Use a dry cloth only, no chemical cleaners.

Glass: We recommend using a strong alcohol such as isopropyl alcohol. Note: some modern cleaning solutions can contain chemicals that can leave a greasy film on glass.

Gilt Wood: Use a dry cloth only.

Lacquered Furniture: Furniture polish

-Any decorative parts made from other materials must be removed and cleaned separately to avoid damage.